

Adapt9S12C32 H1

Pin #

1 PM2
2 PM4
3 PM5
4 PM3
5 PJ7
6 PT7
7 PT6
8 PT5
9 PT4
10 PT3
11 PT2
12 PT1
13 PT0
14 PB7
15 PB6
16 PB5
17 PB4
18 PB3
19 PB2
20 PB1
21 PB0
22 AN00
23 AN01
24 AN02
25 AN04

26 AN07
27 AN06
28 AN05
29 AN04
30 VRH
31 VRL
32 PE3
33 PE4
34 PE2
35 PA7
36 PA6
37 PA5
38 PA4
39 PA3
40 PA2
41 PA1
42 PA0
43 PE7
44 RESET*
45 PE0/XIRQ*
46 PE1/IRQ*
47 VCC
48 PJ6

Emplant H1

Pin #

PD2
PD3
PD4
PD5
PD1
PA7
PA6
PA5
PA4
PA3
PA2
PA1
PA0
PB7
PB6
PB5
PB4
PB3
PB2
PB1
PB0
PE0
PE1
PE2
PE3

PE7
PE6
PE5
PE4
VRH
VRL
STRA
ECLK
STRB
PC0
PC1
PC2
PC3
PC4
PC5
PC6
PC7
RESERVE
RESET
XIRQ*
IRQ*
VCC
PD0

49 GND
50 GND

GND
GND